

# INSTALLATION GUIDELINES

## PARADISE LAMINATE - WET AREAS



# PARADISE LAMINATE - WET AREAS

## INSTALLATION GUIDELINES

### FOR BATHROOM, KITCHEN & LAUNDRY ROOM INSTALLATIONS

Paradise Laminate Flooring has Atroguard water resistant technology and may be installed in wet areas including kitchens, bathroom and laundry rooms providing areas do not have waste/overflow drains subject to local building codes. Paradise Laminate Flooring may not comply with some regulatory requirements for waterproofing in identified wet rooms.

- Paradise Laminate is not suitable to be installed in pool areas, saunas or shower recesses.
- It is important to seal any cut planks to ensure superior and warranted performance. When a flooring plank is cut to fit (either end cuts or side cuts), a sealant is always required around the perimeter of the installation.

- Installations where the flooring planks continue from other areas, the use of a transition trim is required to create a separate raft. Accommodating a 10mm gap between the planks and the adjoining area.
- Fill the expansion spaces with a 10mm compressible PE foam backer rod and cover with a flexible 100% silicone sealant to the entire perimeter of the installation. Do not use an acrylic sealant.
- Prior to installing mouldings, apply silicone sealant to the portion of the moulding or transition that will contact directly with the flooring surface.
- Install mouldings and immediately wipe away any excess silicone sealant.
- Apply silicone sealant at connections to doorframes or any other fixed objects.
- Branded and generic silicone tubes are available in any local home centre or hardware location.

### Paradise Laminate - Wet Areas - Installation Guidelines

**Document ID: 1000053**

**Revision No: 01**

**Date modified: 04/09/2023**

---

Signature Floorcoverings Pty Ltd  
ABN 45 007 172 938  
PO Box 1122 Epping 3076 VIC Australia  
13 Wurundjeri Drive, Epping 3076 VIC Australia  
Tel: 1800 150 554  
[www.signaturefloors.com.au](http://www.signaturefloors.com.au)

15 Bath Street, Parnell Auckland 1052 New Zealand  
Tel: 0800 150 555  
[www.signaturefloors.co.nz](http://www.signaturefloors.co.nz)