

# RECOMMENDED ADHESIVES



# RECOMMENDED ADHESIVES

	Stick Vinyl Planks	Sheet	Rubber	Carpet Tile*	Axminster & Wilton	Needlepunch	Wovn Tiles
Ardex	<p>We are currently working on our Stick Vinyl Planks recommended adhesives. In the interim, please contact Tony Calder on +64 21 287 6876 or tony.calder@signaturefloors.co.nz</p>	<p>We are currently working on our Sheet recommended adhesives. In the interim, please contact Tony Calder on +64 21 287 6876 or tony.calder@signaturefloors.co.nz</p>	AF172 (HS) AF545 (2P)	AF236 (PS)			
Holdfast			Holdfast 451 (2P)	Holdfast 777 (PS) Holdfast 640 (PS) roll	Holdfast 104 (DSI) Holdfast 108 (DSI)		Holdfast 416 (SPS) Holdfast 772 (HS) Holdfast 777 (PS)
Mapei			Ultrabond V4SP (HS) Ultrabond VS90 plus (HS) Adesilex G19 (2P) Ultrabond MS 4LVT (TC)	Ultrabond Eco fix (PS)*	Ultrabond Eco170 (DSI)	Ultrabond Turf (OD) Ultrabond Eco V4SP (DSI) Ultrabond Eco 170 (DSI)	Ultrabond Eco Fix* Ultrabond Eco 380 Ultrabond Eco V4SP Ultrabond Eco V4 Evolution Ultrabond Eco VS90 Plus Ultrabond Eco MS 4 LVT Wall*
MJS			MJS Maxbond MPU (2P) MJS Enviro 2012 (HS)	MJS Enviro 2009 (PS)	Enviro 2010 (HS)	MJS 006 (OD)	MJS Enviro 2012 (HS)
Nexus			NA870 (HS) TBC NA560 (2P)	NA840 (PS)	Nexus 910 (HS)	Nexus 485 (OD)	NA870 (HS)
RLA			RLA 1718 (2P)	RLA GS300 (PS) RLA GS444 (PS) Polymer 999 (PS)	Polymer 300 (DSI)		RLA GS220 (HS) RLA GS300 (PS) Polymer 265 (HS) Polymer 365 (HS)

\*Must use U1 trowel

# RECOMMENDED ADHESIVES

	Stick Vinyl Planks	Sheet	Rubber	Carpet Tile*	Axminster & Wilton	Needlepunch	Wovn Tiles
<b>Roberts</b>	We are currently working on our Stick Vinyl Planks recommended adhesives. In the interim, please contact Tony Calder on +64 21 287 6876 or tony.calder@signaturefloors.co.nz	We are currently working on our Sheet recommended adhesives. In the interim, please contact Tony Calder on +64 21 287 6876 or tony.calder@signaturefloors.co.nz	Roberts 555 (2P)	Roberts 656 (PS) Roberts 585 (PS)	Roberts 95 (DSI) Roberts 59 (DSI) Roberts 100 (DSI) Roberts 85 (DSI)	Roberts 6037 (OD) Roberts 85 (DSI)	Roberts 200 (HS) Roberts 285 (HS)
<b>Uzin</b>			KE66 (HS) KR430 (TC)	U500 (PS)	UZ57 (DSI)	UZ57 (DSI) KE2000S (DSI)	2000SE (HS) KE66 (HS)

\* All pressure sensitive adhesives MUST be applied with a V1 trowel for cushioned backed carpet tiles.

Substrate porosity and environmental factors will have an effect on the open time of adhesives, please ensure all adhesives are applied as per manufacturer's instructions, ensuring correct spread rates and transfer. Failure to comply may affect any warranty conditions.

**For further technical information please contact adhesive manufacturer.**

<b>Ardex</b>	1800 224 070	<b>Mapei</b>	07 3276 5000
<b>RLA</b>	1800 242 931	<b>Uzin</b>	0419 169 925
<b>Holdfast</b>	1800 242 931	<b>MJS</b>	0438 424 949
<b>Roberts</b>	1800 242 931	<b>Nexus</b>	03 9706 4022

**(PS)** Pressure Sensitive    **(SPS)** Semi Pressure Sensitive    **(HS)** Hard Set    **(TC)** Total Cure    **(2P)** Two Component    **(OD)** Outdoor    **(DSI)** Direct Stick Indoor

## Recommended Adhesives

**Document ID: 100044**

**Revision No: 06**

**Date modified: 27/02/2024**

---

Signature Floorcoverings Pty Ltd  
ABN 45 007 172 938  
PO Box 1122 Epping, 3076 VIC Australia  
13 Wurundjeri Drive, Epping 3076 VIC Australia  
Tel: 1800 150 554  
**[www.signaturefloors.com.au](http://www.signaturefloors.com.au)**

15 Bath Street, Parnell Auckland 1052 New Zealand  
Tel: 0800 150 555  
**[www.signaturefloors.co.nz](http://www.signaturefloors.co.nz)**

